Electrical Equipment and Instruments

Item No.	Part No.	Quantity	Description	Notes
			DYNAMO	
†2300	52550	1	Dynamo (22250)	
†2301	52550R	1	Reconditioned Dynamo	
†2302	52547	1	Dynamo Pulley	
†2303	52220	1	,, and Water Pump Support Strap	
*†2304	52221	1	,, Front Support Link	
*†2305	52222	1	,, ,, ,, Pivot Pin	
*†2306	FB105/13	1	,, Fixing Bolt—Front	
†2307	50622	1	,, Rear Support	
*†2308	FS105/5	1	,, ,, ,, Setscrew	
*†2309	FB105/7	1	,, Fixing Bolt—Rear	
†2310	52550/1	1 set	,, Brushes (227627)	
			STARTER	
*†2320	54355	1	Starter Motor (25025)	
*†2321	54355R	1	Reconditioned Starter Motor	
*†2322	54355/1	1 set	Starter Brushes (251187)	
*†2323	54355/2	1	,, Pinion and Sleeve (250849)	
*†2324	54355/3	1	,, Main Drive Spring (250404)	
*†2325	FB106/10	1	,, Fixing Bolt	
			COIL AND DISTRIBUTOR	
*†2330	54641	1	Ignition Coil Acorn Nut	
†2331	54640	1	,, ,, (45020) less Acorn Nut	
*†2332	52384	1	H.T. Lead to Distributor	
*†2333	J54516	1	Distributor Lucas Type DM2	
*†2334	J54516R	1	Reconditioned Distributor	
*†2335	J54516/1	1	Securing Plate Assembly (418191)	
*†2336	J54516/2	1	Distributor Cap Assembly (418871)	
*†2337	J54516/3	1	Brush and Springs (418856)	
*†2338	J54516/4	1	Rotor Arm (400051)	
*†2339	J54516/5	1	Contact Set (416617)	
*†2340	J54516/6	1	Condenser (418654)	
*†2341	J54516/7	1	Cam (496076)	
*†2342	J54516/8	1 set	Auto. Advance Springs (406136/S)	
*†2343	J54516/9	2	Weight Assembly (418321)	
*†2344	J54516/10	1	Shaft and Action Plate (419953)	
*†2345	J54516/11	1	Vacuum Unit, complete (419972)	
*†2346	J54516/12	1	Bush (419430)	
*†2347	J54516/13	1	Driving Dog (419518)	
*†2348	J54516/14	1	Sundry Part Kit (419644)	
*†2349	J54653	1	Rubber Cover Distributor	
*†2350	J54432	5	Grommet for Distributor	
*†2351	FD104/7	1	Distributor Fixing Stud	
*†2352	52174	1	,, Spacing Collar	
†2353	52226	1	Suction Pipe Complete	
			PLUGS AND LEADS	
†2362	50855	4	Spark Plug Champion L.10	
*†2363	50856AS	4	,, ,, Cover, complete	
*†2364	50857	4	,, ,, ,, Clip	
*†2365	50858	4	,, ,, ,, Screw	
*†2366	50859	4	,, ,, ,, Seal	

LUCAS PART No's

Item No.	Part No.	Quantity	Description	Notes
*†2367	52092	1	H.T. Lead 1, 24 in.	
*†2368	52093	1	,, ,, 2, 27 in.	
*†2369	52094	1	,, ,, 3, 29 in.	
*†2370	52092	1	,, ,, 4, 24 in.	
*†2371	J54571	1	Ignition Lead Support Assembly	
*†2372	2162x10		,, ,, ,, Grommet	
			WIRING	
			De-luxe (R.H.D.)	
†2380	J54604	1	Main Harness	
†2381	J54615	1	Negative Battery Cable—Battery to Solenoid Starter Switch	
†2382	J54616	1	Positive Battery Cable to Earth	
†2383	J54614	1	Lead—Solenoid Switch to Starter	
†2384	J54613	1	Engine to Chassis Copper Braid Cable	
†2385	J54612	1	Fog Lamp Extension Lead	
†2386	J54605	1	Panel Connector Harness	
†2387	J54607	1	Boot Harness	
†2388	996822	1	Body Lead—To Interior Light	
†2389	996823	1	,, ,, —To Trafficator—R.H.	
†2390	996824	1	,, Harness—To Trafficator—L.H. and Rear Light	
†2391	J54603	1	,, Harness	
			De-luxe (L.H.D.)	
†2400	J54617	1	Main Harness	
†2401	J54615	1	Negative Battery Cable—Battery to Solenoid Starter Switch	
†2402	J54616	1	Positive Battery Cable to Earth	
†2403	J54613	1	Engine to Chassis Copper Braid Cable	
†2404	J54614	1	Lead—Solenoid Switch to Starter	
†2405	J54612	1	Fog Lamp Extension Lead	
†2406	J54605	1	Panel Connector Harness	
†2407	J54607	1	Boot Harness	
†2408	996822	1	Body Lead—To Interior Light	
†2409	996823	1	,, ,, — ,, Trafficator—R.H.	
†2410	996824	1	,, Harness—To Trafficator—L.H. and Rear Lights	
†2411	J54603	1	,, Harness	
			Standard (R.H.D.)	
†2420	J54620	1	Main Harness	
†2421	J54615	1	Negative Battery Lead to Starter Solenoid Switch	
†2422	J54616	1	Positive Battery Cable to Earth	
†2423	J54614	1	Lead—Solenoid Switch to Starter	
†2424	J54613	1	Copper Braid Cable—Engine to Earth	
†2425	995722	1	Body Lead to R.H. Trafficator	
†2426	995723	1	,, Harness—To L.H. Trafficator and Rear Lights	
†2427	J54622	1	Boot Harness	
†2428	J54619	1	Body Harness	
			Standard (L.H.D.)	
†2432	J54623	1	Main Harness	
†2433	J54615	1	Negative Battery Cable—To Starter Solenoid Switch	
†2434	J54616	1	Positive ,, ,, — ,, Earth	

* *Denotes items common to Jupiter*

† *Denotes items not illustrated*

Always quote engine, body-frame, part and item numbers in full.